

HotSpring Spa - Stockholm Sauna - Roof Assembly Kit

Roof Assembly



When your roof kit is unpacked it should look like this.

Start by mounting the roof trusses on top of the sauna cabin. Screw the trusses to the cabin roof using screws provided.



The two trusses with panelling should be mounted on either end of the sauna with the panel side facing out.



Next fit one of the roof panels. The spruce T & G panelling should be facing down. Please refer to the roof layout diagram for exact positioning.



Screw the roof panel to the trusses at intervals of approx. 200mm, using the screws provided.



Fit the second roof panel and fix in place with screws provided, ensuring that the two panels meet at the ridge.



So far, the roof should look like this.

HotSpring Spa - Stockholm Sauna - Roof Assembly Kit

Tiling

You will find that the back of each length of roof tile has an adhesive strip. Before fitting each tile please remove the tape covering this strip. The roof tiles are pinned in place using the pins provided.



Start at the bottom of one roof panel. The lowest layer of tiles needs to be double thickness, one section on top of the other, staggered so that the no wood is visible. Allow a 20mm overhang.

Work up the roof to the ridge. The final section on the first side should overlap the ridge. The final section on the second side should overlap the first side top tile. This may be trimmed.



Finish the ridge with the ridge section provided. This should be screwed into place as shown with the screws provided.

Along each edge, cut the tiles to an even finish leaving a 20mm overhang.



Finally fit the final end using pins provided.