



HELO SAUNA CABIN
INSTALLATION SITE REQUIREMENT SURVEY

***** VERY IMPORTANT *****
FAILURE TO COMPLETE AND RETURN THIS FORM MAY RESULT
IN DELAYS AND/OR EXTRA CHARGES

The Helo sauna cabin is constructed of prefabricated wall and ceiling panels, which are assembled on a wooden base. In order that the installation can be carried out successfully the following requirements are fundamental.

SITE INFORMATION

In order to ensure there are no delays on the first day of installation, please confirm the following site information. If there are **any specific site requirements**, such as Health and Safety induction, boots, hard hats, task lighting/own lighting, etc., please confirm this information below. In addition, please send detailed instructions and/or a map of how to find the site from the nearest main road.

Comments & Signature:

SPACE

The sauna cabin is supplied in sections which are fitted together. In order to facilitate the construction of the cabin, the proposed area should be at least 100mm greater than the actual cabin size. **Please confirm below that sufficient space** will be available for construction of the sauna cabin.

Comments & Signature:

FLOOR

The floor should be level with a water impervious covering, e.g. ceramic/quarry tiles, vinyl or similar, laid prior to the assembly of the sauna. Drainage is not necessary unless the sauna is for heavy commercial use. If drainage is required, the floor should be laid with a level perimeter to support the sauna base frame, with a continuous fall of 1:50 to a central drain. **Please confirm below that the floor and necessary drainage** will be ready.

Comments & Signature:

TREATMENT OF SAUNA WALLS

The exterior panelling of the sauna may be treated with a preservative, e.g. “Solignum Timbertone”. Treatment will protect the exterior of the sauna against moisture and the effects of UV rays. Interior walls should not be treated.

VENTILATION

The sauna has a low level vent which allows fresh air intake, and a high level outlet vent located on the opposite side of the cabin to encourage air circulation. The 100mm gap around the sauna cabin should be naturally vented, however if the area is completely enclosed a 9” x 9” air brick (at a min height of 2m) should be provided. **Please confirm below that suitable space and ventilation** will be provided.

Comments & Signature:

ELECTRICAL SUPPLY

An isolated electrical supply of suitable amperage/voltage is required for the sauna stove. The supply should terminate at high level to enable connection to the heater via ducting in the sauna wall. See the table below for different stove specifications. The sauna light/s will be switched from the sauna control panel unless otherwise specified.

TABLE OF TECHNICAL SPECIFICATIONS FOR HELO SAUNA STOVES

Heater Type	Power Rating	240v - 1 phase	415v - 3 phase
PD30	3kW	13 amp	N/A
SKSO 45	4.5kW	20 amp	7 amp
SKSO 60	6kW	25 amp	9 amp
SKSO 80	8kW	35 amp	12 amp
SKLE 901	9kW	40 amp	13 amp
SKLE 1051	10.5kW	45 amp	15 amp
SKLE 1201	12kW	50 amp	20 amp
SKLE 1501	15kW	65 amp	25 amp

If you have specified an automatic water doser for your sauna stove, a 5 amp switched spur and 15mm cold water feed tap should be supplied in a suitable plant room or cupboard location not more than 5m from the sauna stove. **Please confirm below that the appropriate electrical/water supply** will be ready.

Comments & Signature:

OTHER INFORMATION

Please specify below what **type of door** you prefer for the sauna and which way you would like the **door to open**.

Type of Door - Wood	or	Glass	Hinges on - Left	or	Right
---------------------	----	-------	------------------	----	-------

Please specify what type of **power supply** will be available for the sauna stove:

Sauna Stove Power Supply -	Three Phase	or	Single Phase
----------------------------	-------------	----	--------------

NON-COMPLIANCE

It is essential that all site requirements are completed prior to installation. Should the site requirements not be completed on the agreed installation date an additional charge will be made for any waiting time or return trips to site. **Please sign below to confirm acceptance of this condition.**

Comments & Signature:

**IF YOU NEED ANY HELP COMPLETING THIS FORM,
OR ARE UNSURE ABOUT ANY ISSUES, PLEASE CONTACT HELO UK
IMMEDIATELY ON 01342-300555**